


MICRO-COMPUTER BASED
DIGITAL INDICATING CONTROLLER
JCM-33A
INSTRUCTION MANUAL



Shinko

Preface

Thank you for the purchase of Micro-computer based Digital Indicating Controller JCM-33A. This manual contains instructions for the mounting, functions, operations and notes when operating the JCM-33A.

For model confirmation and unit specifications, please read this manual carefully before starting operation.

To prevent accidents arising from the misuse of this controller, please ensure the operator using it receives this manual.


Notes

- This instrument should be used according to the specifications described in the manual. If it is not used according to the specifications, it may malfunction or cause fire.
- Be sure to follow the warnings, cautions and notices. If not, it could cause serious injury or accidents.
- The contents of this instruction manual are subject to change without notice.
- Care has been taken to assure that the contents of this instruction manual are correct, but if there are any doubts, mistakes or questions, please inform our sales department.
- This instrument is designed to be installed in a control panel. If not, measures must be taken to ensure that the operator cannot touch power terminals or other high voltage sections.
- Any unauthorized transfer or copying of this document, in part or in whole, is prohibited.
- Shinko Technos CO., LTD. is not liable for any damages or secondary damages incurred as a result of using this product, including any indirect damages.

Safety precautions

(Be sure to read these precautions before using our products.)

The safety precautions are classified into categories: "Warning" and "Caution".

Depending on circumstances, procedures indicated by  Caution may be linked to serious results, so be sure to follow the directions for usage.

Warning

Procedures which may lead to dangerous conditions and cause death or serious injury, if not carried out properly.

Caution

Procedures which may lead to dangerous conditions and cause superficial to medium injury or physical damage or may degrade or damage the product, if not carried out properly.

1. Installation precautions



Caution

This instrument is intended to be used under the following environmental conditions (IEC61010-1): Overvoltage category II, Pollution degree 2

Mount the controller in a place with:

- A minimum of dust, and an absence of corrosive gasses
- No flammable, explosive gasses
- No mechanical vibrations or shocks
- No exposure to direct sunlight, an ambient temperature of 0 to 50°C (32 to 122°F) that does not change rapidly
- An ambient non-condensing humidity of 35 to 85%RH
- No large capacity electromagnetic switches or cables through which large current is flowing
- No water, oil or chemicals or where the vapors of these substances can come into direct contact with the unit

Note: Do not install this instrument near flammable material even though the case of this instrument is made of flame resistant resin.

Avoid setting this instrument directly on flammable material.

2. Wiring precautions



Caution

- Use the solderless terminal with an insulation sleeve that fits in the M3 screw when wiring the JCM-33A Series.
- The terminal block of this instrument is designed to be wired from the left side. The lead wire must be inserted from the left side of the terminal, and fastened with the terminal screw.
- Tighten the terminal screw within the specified torque. If excessive force is applied to the screw when tightening, the terminal screw or case may be damaged.
- Do not apply a commercial power source to the sensor which is connected to the input terminal nor allow the power source to come into contact with the sensor.
- This controller does not have built-in power switch, circuit breaker or fuse. It is necessary to install them near the controller.
(Recommended fuse: Time-lag fuse, rated voltage 250V AC, rated current 2A)
- When using a 24V AC/DC for the power source, do not confuse the polarity when it is DC.

3. Running and maintenance precautions



Warning

- It is recommended that the PID auto-tuning be performed on the trial run.
- Do not touch live terminals. This may cause electric shock or problems in operation.
- Turn the power supplied to the instrument OFF before retightening the terminal and cleaning.
Working or touching the terminal with the power switched ON may result in severe injury or death due to Electric Shock.
- Use a soft, dry cloth when cleaning the instrument.
(If paint thinner is used, it might deform or tarnish the unit)
- As the display section is vulnerable, do not strike or scratch it with a hard object.

--- CONTENTS ---


1. Model name	
1.1 Explanation of model name	6
1.2 Rated input	7
1.3 How to read the model nameplate	7
2. Name and functions of the sections	8
3. Mounting to control panel	
3.1 Site selection	10
3.2 External dimension	10
3.3 Panel cutout	10
3.4 CT (current transformer) external dimension	11
3.5 Mounting	11
4. Wiring connection	
4.1 Terminal arrangement	12
4.2 Wiring connection examples	13
5. Setup	
5.1 Setup flow chart	16
5.2 Main setting mode	
SV1	17
SV2	17
5.3 Sub setting mode	
AT setting/Auto-reset setting	17
OUT1 proportional band setting	18
OUT2 proportional band setting	18
Integral time setting	18
Derivative time setting	18
ARW (Anti-reset windup) setting	18
OUT1 proportional cycle setting	18
OUT2 proportional cycle setting	18
A1 setting	18
A2 setting	19
HB (Heater burnout alarm) setting	19
LA (Loop break alarm) action time setting	19
LA (Loop break alarm) action span setting	19
5.4 Auxiliary function setting mode 1	
Setting value lock selection	20
SV high limit setting	20
SV low limit setting	20
Sensor correction setting	20
Communication protocol selection	20
Instrument number setting	20
Data transfer rate selection	21
Parity selection	21
Stop bit selection	21
5.5 Auxiliary function setting mode 2	
Input type selection	21
Scaling high limit setting	22
Scaling low limit setting	22
Decimal point place selection	22
PV filter time constant setting	22
OUT1 high limit setting	22

OUT1 low limit setting	22
OUT1 ON/OFF action hysteresis setting	22
OUT2 action mode selection	23
OUT2 high limit setting	23
OUT2 low limit setting	23
Overlap band/Dead band setting	23
OUT2 ON/OFF action hysteresis setting	23
A1 action selection	23
A2 action selection	24
A1 action Energized/Deenergized selection	24
A2 action Energized/Deenergized selection	24
A1 hysteresis setting	24
A2 hysteresis setting	24
A1 action delayed timer setting	24
A2 action delayed timer setting	24
Direct/Reverse action selection	24
AT bias setting	25
SVTC bias setting	25
SV2 indication selection	25
Output status selection when input burnout	25
OUT/OFF key function selection	25
5.6 Control output OFF function	26
5.7 Auto/Manual control function	26
5.8 Output manipulated variable indication	26
6. Running	27
7. Action explanation	
7.1 OUT1 action	28
7.2 Heater burnout alarm action (option)	28
7.3 OUT1 ON/OFF action	29
7.4 OUT2 (Heating/Cooling control) action (option)	30
7.5 A1 and A2 actions	33
7.6 SV1/SV2 external selection action	34
8. Control action explanations	
8.1 PID	35
8.2 PID auto-tuning of this controller	35
8.3 Auto-reset (offset correction)	36
9. Specifications	
9.1 Standard specifications	37
9.2 Optional specifications	41
9.3 Option combination	43
10. Troubleshooting	44
11. Character table	46

1. Model name

1.1 Explanation of model name

The series name, control output (OUT1), input and option codes are entered where underlined.



Standard specification

J C M - 3 3 A - <input type="checkbox"/> / <input type="checkbox"/> <input type="checkbox"/>	
Alarm 1 (A1)	A : : : Alarm action can be selected by keypad operation.*1
Control output (OUT1)	R : : : Relay contact
	S : : : Non-contact voltage (for SSR drive)
	A : : : DC current
Input	M : : Multi-range *2
Supply voltage	1 24V AC/DC *3

*1: 10 types of alarm action (including No alarm action) and Energized/Deenergized are selectable by keypad operation.

*2: Input types (10 thermocouple, 2 RTD, 2 DC current and 4 DC voltage types) can be selected by keypad operation. For DC current input, 50Ω shunt resistor must be connected between input terminals.

*3: For the supply voltage, 100 to 240V AC is standard. When ordering 24V AC/DC, enter "1" after the input code.

Optional specification

Code	Name	
A2	Alarm 2 (A2) (*1)	
W	Heater burnout alarm (*2)	
D <input type="checkbox"/>	Heating/Cooling control (OUT2)	DR: Relay contact output
		DS: Non-contact voltage output
		DA: DC current output
C5	Serial communication (RS-485)	
LA	Loop break alarm (*1)	
SM	SV1/SV2 external selection	
P24	Isolated power output	
BK	Color: Black	
TC	Terminal cover	
IP	Dust-proof/Drip-proof (IP54)	

(*1) If A2 output and LA output are applied together, they share common output terminals.

(*2) For DC current output type, Heater burnout alarm output is not available.

Option combination

	A2	LA	W	D <input type="checkbox"/>	P24	C5	SM	BK	TC	IP
Combination 1	O	O	O	-	-	O	-	O	O	O
Combination 2	O	O	-	O	-	O	-	O	O	O
Combination 3	-	-	O	O	-	O	-	O	O	O
Combination 4	O	O	-	-	O	O	-	O	O	O
Combination 5	O	O	O	-	-	-	O	O	O	O
Combination 6	O	O	-	O	-	-	O	O	O	O
Combination 7	-	-	O	O	-	-	O	O	O	O
Combination 8	O	O	-	-	O	-	O	O	O	O

D : DR, DS, DA

1.2 Rated input

Input type	Input range		Resolution
K	-200 to 1370 °C	-320 to 2500 °F	1°C(F)
	-199.9 to 400.0 °C	-199.9 to 750.0 °F	0.1°C(F)
J	-200 to 1000 °C	-320 to 1800 °F	1°C(F)
R	0 to 1760 °C	0 to 3200 °F	1°C(F)
S	0 to 1760 °C	0 to 3200 °F	1°C(F)
B	0 to 1820 °C	0 to 3300 °F	1°C(F)
E	-200 to 800 °C	-320 to 1500 °F	1°C(F)
T	-199.9 to 400.0 °C	-199.9 to 750.0 °F	0.1°C(F)
N	-200 to 1300 °C	-320 to 2300 °F	1°C(F)
PL-II	0 to 1390 °C	0 to 2500 °F	1°C(F)
C (W/Re5-26)	0 to 2315 °C	0 to 4200 °F	1°C(F)
Pt100	-199.9 to 850.0 °C	-199.9 to 999.9 °F	0.1°C(F)
	-200 to 850 °C	-300 to 1500 °F	1°C(F)
JPt100	-199.9 to 500.0 °C	-199.9 to 900.0 °F	0.1°C(F)
	-200 to 500 °C	-300 to 900 °F	1°C(F)
4 to 20mA DC	-1999 to 9999 *1, *2		1
0 to 20mA DC	-1999 to 9999 *1, *2		1
0 to 1V DC	-1999 to 9999 *1		1
0 to 5V DC	-1999 to 9999 *1		1
1 to 5V DC	-1999 to 9999 *1		1
0 to 10V DC	-1999 to 9999 *1		1


*1: For DC input, input range and decimal point place can be changed.

*2: Connect 50Ω shunt resistor (sold separately) between input terminals.

1.3 How to read the model nameplate

Model nameplates are attached to the case and the inner assembly.

When the supply voltage is 24V AC/DC, "1" is entered before the option code.




(1): Model name

(2): Option name

(3): Instrument number

2. Name and functions of the sections



(Fig. 2-1)

- (1) PV display
Indicates the Process variable (PV) with a red LED.
- (2) SV display
Indicates the Setting value (SV) or Manipulated variable (MV) with a green LED.
- (3) SV1 indicator
Lights up with a green LED when SV1 is selected.
- (4) SV2 indicator
Lights up with a yellow LED when SV2 is selected.
- (5) OUT1 indicator
When OUT1 or Heating output is on, a green LED lights up.
(For the DC current output type, this blinks corresponding to the output manipulated variable in a 0.25 second cycle)
- (6) OUT2 indicator
When OUT2 is on, a yellow LED lights up.
(For the DC current output type, this blinks corresponding to the output manipulated variable in a 0.25 second cycle)
- (7) HB indicator
When Heater burnout alarm output or sensor burnout alarm output is on, a red LED lights up.
(When Heater burnout alarm is added and if indication is the overscale or underscale, a red LED lights up as well)
- (8) A1 indicator
When A1 output is on, a red LED lights up.
- (9) A2/LA indicator
When A2 or LA output is on, a red LED lights up.

(10) AT indicator

A yellow LED blinks during auto-tuning or auto-reset.

(11) TX/RX indicator

A yellow LED lights during serial communication TX output (transmission).

(12) Increase key (\triangle): Increases the numeric value.

(13) Decrease key (∇): Decreases the numeric value.

(14) Mode key (\odot): Selects the setting mode or registers the setting value.

(By pressing the Mode key, the setting value or selected value can be registered.)

(15) OUT/OFF key ($\textcircled{1}$)

- If OUT/OFF function is selected from OUT/OFF function selection, the control output is turned on or off.

Once the control output OFF function is enabled, the function cannot be released even if the power to the instrument is turned OFF and turned ON again.

To cancel the function, press the OUT/OFF key again for approx. 1 second.

- If Auto/Manual control function is selected from OUT/OFF function selection, automatic control is performed when the power to the controller is turned on. In this status, if the OUT/OFF key is pressed, the automatic control output is switched to manual control output and vice versa. However, this function can be switched only in the PV/SV display mode.



Notice

When setting the specifications and functions of this controller, connect the terminals 2 and 4 for power source first, then set them referring to “5. Setup” before performing “3. Mounting to control panel” and “4. Wiring connection”.

(Be sure to perform input specification change at this time.)

3. Mounting to control panel

3.1 Site selection


This instrument is intended to be used under the following environmental conditions (IEC61010-1):

Overvoltage category II, Pollution degree 2

Mount the controller in a place with:


- (1) A minimum of dust, and an absence of corrosive gases
- (2) No flammable, explosive gasses
- (3) No mechanical vibrations or shocks
- (4) No exposure to direct sunlight, an ambient temperature of 0 to 50°C (32 to 122°F) that does not change suddenly
- (5) An ambient non-condensing humidity of 35 to 85%RH
- (6) No large capacity electromagnetic switches or cables through which large current is flowing
- (7) No water, oil or chemicals or where the vapors of these substances can come into direct contact with the unit

3.2 External dimension




(Fig. 3.2-1)

3.3 Panel cutout



(Fig. 3.3-1)

3.4 CT (Current transformer) external dimension



CTL-6-S (for 5A, 10A and 20A)

CTL-12-S36-10L1 (for 50A)

(Fig. 3.4-1)

3.5 Mounting




Notice

As the case is made of resin, do not use excessive force while screwing in the mounting bracket, or the case or screw type mounting bracket could be damaged. The torque is approximately 0.12N•m.

Mounting panel thickness is within 1 to 15mm.

Insert the instrument from the front side of the panel.

Attach the mounting bracket by the holes at the top and bottom of the case and secure in place with the screws.



(Fig. 3.5-1)

4. Wiring connection




Warning

Turn the power supply to the instrument off before wiring or checking.

Working or touching the terminal with the power switched on may result in severe injury or death due to Electric Shock.

Moreover, the instrument must be grounded before the power supply to the instrument is turned on.

4.1 Terminal arrangement



(Fig. 4.1-1)

- OUT1 : Control output 1 (Heating output)
- OUT2 : Control output 2 (Cooling output)
- A1 : Alarm 1 output
- A2 : Alarm 2 output
- LA : Loop break alarm output
- HB : Heater burnout alarm output
- P24 : Isolated power output
- RS-485: Serial communication (RS-485)
- SV2 : 2nd main setting
- CT : CT input
- TC : Thermocouple
- RTD : Resistance temperature detector
- DC : DC current or DC voltage





Notice

- The terminal block of JCM-33A series is designed to be wired from the left side. The lead wire must be inserted from the left side of the terminal, and fastened with the terminal screw.
- Dotted lines show options, and if the option is not designated, its terminals are not mounted.
- If A2 (option) and Heater burnout alarm (option) are applied together, use terminals 17-18 for A2, and 8-9 for the Heater burnout alarm.
- If the Heating/Cooling control (option) and Heater burnout alarm (option) are applied together, use terminals 8-9 for the Heating/Cooling control, and 17-18 for the Heater burnout alarm.
- When A2 (option) and LA (option) are added together, they share common output terminals.
- If the Isolated power output (option) is added, Heating/Cooling control (option) and Heater burnout alarm (option) cannot be applied.

● Lead wire solderless terminal

Use a solderless terminal with isolation sleeve that fits in the M3 screw as shown below. The tightening torque should be 0.6N•m to 1.0N•m.

Solderless terminal	Manufacturer	Model name	Tightening torque
Y type	Nichifu Terminal Industries CO.,LTD.	1.25Y-3	0.6N•m Max. 1.0N•m
	Japan Solderless Terminal MFG CO.,LTD.	VD1.25-B3A	
Round type	Nichifu Terminal Industries CO.,LTD.	1.25-3	
	Japan Solderless Terminal MFG CO.,LTD.	V1.25-3	



(Fig. 4.1-2)

4.2 Wiring connection examples




Notice


- Use a thermocouple and compensating lead wire according to the sensor input specifications of this controller.
- Use the 3-wire RTD according to the sensor input specifications of this controller.
- This controller does not have built-in power switch, circuit breaker or fuse. It is necessary to install them in the circuit near the external controller. (Recommended fuse: Time-lag fuse, rated voltage 250V AC, rated current 2A)
- When using a 24V AC/DC for the power source, do not confuse the polarity when it is DC.
- When using a relay contact output type, use a relay externally according to the capacity of the load to protect the built-in relay contact.
- When wiring, keep the input wire (Thermocouple, RTD, etc.) away from AC sources or load wires to avoid external interference.
- Use a thick wire (1.25 to 2.0mm²) for the earth ground.

[Heater burnout alarm output]

- (1) **This alarm is not available for detecting heater current under phase control.**
- (2) Use the current transformer (CT) provided, and pass one lead wire of the heater circuit into the hole of the CT.
- (3) When wiring, keep CT wire away from any AC source and load wire to avoid external interference.



[JCM-33A-S/E]



- To prevent the unit from harmful effects of unexpected high level noise, it is recommended that a surge absorber be installed between the electromagnetic switch coils.
- AC or DC is available for supply voltage 24V, however, do not confuse the polarity when DC is applied.

5. Setup

For the thermocouple and RTD input, the sensor input character and temperature unit are indicated on the PV display and the input range high limit value is indicated on the SV display for approx. 3 seconds after the power is turned on. See (Table 5-1).

For DC input, the sensor input character is indicated on the PV display and the scaling high limit value is indicated on the SV display. See (Table 5-1).

If any other value is set in the scaling high limit setting, the set value is indicated on the SV display.

During this time, all outputs and the LED indicators are in off status.

Control will start indicating the process variable on the PV display and SV1 or SV2 on the SV display.


While control output OFF function is working, *OFF* is indicated on the PV display.

To release the function, press the OUT/OFF key for approx. 1 second.

(Table 5-1)

Sensor input	°C		°F	
	PV display	SV display	PV display	SV display
K	<i>k C</i>	1370	<i>k F</i>	2500
	<i>k C</i>	4000	<i>k F</i>	7500
J	<i>J C</i>	1000	<i>J F</i>	1800
R	<i>r C</i>	1760	<i>r F</i>	3200
S	<i>s C</i>	1760	<i>s F</i>	3200
B	<i>b C</i>	1820	<i>b F</i>	3300
E	<i>E C</i>	800	<i>E F</i>	1500
T	<i>T C</i>	4000	<i>T F</i>	7500
N	<i>n C</i>	1300	<i>n F</i>	2300
PL-II	<i>PL2C</i>	1390	<i>PL2F</i>	2500
C (W/Re5-26)	<i>c C</i>	2375	<i>c F</i>	4200
Pt100	<i>PT C</i>	8500	<i>PT F</i>	9999
	<i>PT C</i>	850	<i>PT F</i>	1500
JPt100	<i>JPT C</i>	5000	<i>JPT F</i>	9000
	<i>JPT C</i>	500	<i>JPT F</i>	900
4 to 20mA DC	<i>420A</i>	Scaling high limit value		
0 to 20mA DC	<i>020A</i>			
0 to 1V DC	<i>0 1B</i>			
0 to 10V DC	<i>0 10B</i>			
1 to 5V DC	<i>1 5B</i>			
0 to 5V DC	<i>0 5B</i>			

5.1 Setup flowchart






- $\Delta + \text{Enter}$: Press the Enter key while holding down the Δ key.
- $\nabla + \text{Enter}$ (Approx. 3s): Press the Enter key for approx. 3 seconds while holding down the ∇ key.
- $\Delta + \nabla + \text{Enter}$ (Approx. 3s): Press the Enter key for approx. 3 seconds while holding down the Δ and ∇ keys.
- Dotted lines show options and are indicated only when the option is applied.

(*1): When Auto/Manual control function is selected during Enter key selection, the control output OFF function does not work even if the Enter key is pressed, but manual control is selected.

5.2 Main setting mode

The main setting mode can be selected by pressing the  key.

The setting value can be increased or decreased by pressing the  or  key.

The setting value is registered by pressing the  key, and the mode reverts to the PV/SV display mode.



SV1 []

- Sets SV1.
- Setting range: SV low limit to SV high limit, or scaling low limit value to scaling high limit value
- Default value: 0°C


SV2 []

- Sets SV2.
- Available only when SV1/SV2 external selection (option) is applied.
- Setting range: SV low limit to SV high limit, or scaling low limit value to scaling high limit value
- Default value: 0°C

5.3 Sub setting mode

The sub setting mode can be selected by pressing the  key while the  key is being pressed.



The setting value can be increased or decreased by pressing the  or  key.

The setting value is registered by pressing the  key, then the next setting item is selected.

AT setting/Auto-reset setting []

- Sets AT (auto-tuning) or Auto-reset (offset correction).
- Auto-reset can be performed only in PD or P action.
(Auto-reset cannot be performed when the control action is PID, PI, ON/OFF action)
- Default value: AT cancellation, Auto-reset cancellation.

[Auto-tuning]

- If Auto-tuning performance is designated, the AT indicator blinks and the mode reverts to the PV/SV display mode.
When Auto-tuning is finished, the AT indicator is turned off and P, I, D, ARW values are automatically set.
- During auto-tuning, none of the settings can be carried out.
- If Auto-tuning is cancelled during the process, P, I, D, ARW values return to the former values.
- If  key (OUT/OFF key) is pressed during auto-tuning, control output OFF function works, and pressing the  key again cancels the PID auto-tuning.
- If PID auto-tuning does not finish in 4 hours after it is started, PID auto-tuning is cancelled automatically.

[Auto-reset]

- If auto-reset performance is designated, the offset correction immediately starts, (correction value is automatically set, and AT indicator blinks) and the mode reverts to the PV/SV display mode.
- To prevent key misoperation, other settings cannot be performed for 4 minutes after auto-reset starts.
After auto-reset is completed, AT indicator is turned off and all settings are available.

<p>OUT1 proportional band setting [P_1]</p> <ul style="list-style-type: none"> • Sets OUT1 proportional band. The control action becomes ON/OFF action when set to 0 or 0.0. • Setting range: 0 to 1000°C (0 to 2000°F) With a decimal point, 0.0 to 999.9°C (0.0 to 999.9°F) With DC input, 0.0 to 100.0% • Default value: 10°C
<p>OUT2 proportional band setting [$P_2 - b$]</p> <ul style="list-style-type: none"> • Sets OUT2 proportional band. The control action becomes ON/OFF action for OUT2 when set to 0.0. • Not available if Heating/Cooling control (option) is not added or if OUT2 is ON/OFF action. • Setting range: 0.0 to 10.0 times (multiplying factor to OUT1 proportional band) • Default value: 1.0 times
<p>Integral time setting [I]</p> <ul style="list-style-type: none"> • Sets the integral time. Setting the value to 0 disables the function. (It becomes PD action) • Not available if OUT1 is ON/OFF action. • Setting range: 0 to 1000 seconds • Default value: 200 seconds
<p>Derivative time setting [D]</p> <ul style="list-style-type: none"> • Sets the derivative time. Setting the value to 0 disables the function. (It becomes PI action) • Not available if OUT1 is ON/OFF action. • Setting range: 0 to 300 seconds • Default value: 50 seconds
<p>ARW (Anti-reset windup) setting [r_i]</p> <ul style="list-style-type: none"> • Sets the anti-reset windup. • Available only for PID action. • Setting range: 0 to 100% • Default value: 50%
<p>OUT1 proportional cycle setting [c]</p> <ul style="list-style-type: none"> • Sets OUT1 proportional cycle. (Not available for ON/OFF action and DC current output type) • With the relay contact output type, if the proportional cycle time is decreased, the frequency of the relay action increases and the life of the relay contact is shortened. • Setting range: 1 to 120 seconds • Default value: 30 seconds for relay contact output type, 3 seconds for non-contact voltage output type
<p>OUT2 proportional cycle setting [$c - b$]</p> <ul style="list-style-type: none"> • Sets OUT2 proportional cycle. Not available for ON/OFF action and DC current output type • Not available if Heating/Cooling control (option) is not added or if OUT2 is ON/OFF action. • Setting range: 1 to 120 seconds • Default value: 30seconds(relay contact output), 3seconds(non-contact voltage output)
<p>A1 setting [H_i]</p> <ul style="list-style-type: none"> • Sets the action point for A1 output. Setting the value to 0 or 0.0 disables the function. (excluding Process high and Process low alarms) • Not available when No alarm action is selected in A1 action selection. • Setting range: See page 19 (Table 5.3-1). • Default value: 0°C

<p>A2 setting [H_L^L]</p> <ul style="list-style-type: none"> • Sets the action point for A2 output. Setting the value to 0 or 0.0 disables the function. (excluding Process high and low alarms) • Not available when A2 (option) is not added or when No alarm action is selected in A2 action selection. • Setting range and default value are the same as those of A1 setting.
<p>HB (Heater burnout alarm) setting [H_{LH}] and [$LH.X$] are alternately displayed]</p> <ul style="list-style-type: none"> • Sets the heater current value for Heater burnout alarm. Setting the value to 0.0 disables the function. • Available only when the option Heater burnout alarm is added. • When OUT1 is off, heater current value shows the former value as when OUT1 was on. • It is recommended to set approx. 80% of the heater current value (setting value) considering the voltage fluctuation. • Self-holding is not available for the alarm output. • Setting range: Rating 5A: 0.0 to 5.0A Rating 10A: 0.0 to 10.0A Rating 20A: 0.0 to 20.0A Rating 50A: 0.0 to 50.0A • Default value: 0.0A
<p>LA (Loop break alarm) action time setting [$L^H - T$]</p> <ul style="list-style-type: none"> • Sets the time to assess the Loop break alarm. • Available only when Loop break alarm (option) is applied. • Setting range: 0 to 200 minutes • Default value: 0 minutes
<p>LA (Loop break alarm) action span setting [$L^H - H$]</p> <ul style="list-style-type: none"> • Sets the temperature to assess the Loop break alarm. • Available only when Loop break alarm (option) is applied. • Setting range: 0 to 150°C (°F), however, with decimal point, 0.0 to 150.0°C (°F) For DC input, 0 to 1500 (The placement of the decimal point follows the selection) • Default value: 0 °C

Setting range of A1 and A2

(Table 5.3-1)






Alarm type	Setting range
High limit alarm	–Input span to input span °C (°F) *1
Low limit alarm	–Input span to input span °C (°F) *1
High/Low limits alarm	0 to input span °C (°F) *1
High/Low limit range alarm	0 to input span °C (°F) *1
Process high alarm	Input range low limit to input range high limit *2
Process low alarm	Input range low limit to input range high limit *2
High limit alarm with standby	–Input span to input span °C (°F) *1
Low limit alarm with standby	–Input span to input span °C (°F) *1
High/Low limits alarm with standby	0 to input span °C (°F) *1

When the input has a decimal point, the negative low limit value is –199.9, and the positive high limit value is 999.9.

*1: For DC input, the input span is the same as the input range scaling span.

*2: For DC input, input range low (high) limit value is the same as the input range scaling low (high) limit value.

5.4 Auxiliary function setting mode 1

In the PV/SV display mode, if the  key is pressed for approx. 3 seconds while the  key is being pressed, Auxiliary function setting mode 1 can be selected. The setting value can be increased or decreased by pressing the  or  key. If the  key is pressed, the setting value is registered and the next setting item is selected.

Setting value lock selection [*Lock*]

- Mode to lock the setting value to prevent setting errors
The setting item to be locked depends on the designation.
When designating Lock, designate Lock 1, 2 or 3 after setting the necessary items in the status Unlock.
- Selecting item
 - (Unlock): All setting values are changeable.
 - Lock 1* (Lock 1): None of the setting values can be changed.
 - Lock 2* (Lock 2): Only main setting value is changeable.
 - Lock 3* (Lock 3): All setting values can be changed, however, changed values return to their former value after the power is turned off because they are not saved in the non-volatile memory. **Do not change any setting item in Auxiliary function setting mode 2. If any item in Auxiliary function setting mode 2 is changed, it will affect other setting items such as SV and Alarm setting.**
- Default value: Unlock

SV high limit setting [*HH*]

- Sets SV high limit.
- Setting range: SV low limit to input range high limit value
For DC input, SV low limit to scaling high limit value
(The placement of the decimal point follows the selection)
- Default value: 1370°C

SV low limit setting [*LL*]

- Sets SV low limit.
- Setting range: Input range low limit value to SV high limit
For DC input, Scaling low limit value to SV high limit
(The placement of the decimal point follows the selection)
- Default value: -200°C

Sensor correction setting [*CS*]

- Sets correction value for the sensor.
(Effective within the input rating value regardless of the sensor correction value)
- Setting range: -100.0 to 100.0°C (°F)
For DC input, -1000 to 1000 (The placement of the decimal point follows the selection)
- Default value: 0.0°C

Communication protocol selection [*CSLL*]




- Selects the communication protocol.
- Available only when Serial communication (option) is applied.
- Selecting item : *CSLL* (Shinko protocol), *CSLLA* (Modbus ASCII mode)
CSLLR (Modbus RTU mode)
- Default value: Shinko protocol




Instrument number setting [*CSLLS*]

- Sets the instrument number. (Communication cannot be carried out unless an instrument number is individually set when communicating by connecting plural instruments in serial communication.)
- Available only when Serial communication (option) is added.
- Setting range: 0 to 95
- Default value: 0

<p>Communication speed selection [c n 4 P]</p> <ul style="list-style-type: none"> • Selects a speed to be equal to the speed of the host computer. Otherwise communication is impossible. • Available only when Serial communication (option) is added. • Selecting item: 24 (2400bps), 48 (4800bps), 96 (9600bps), 192 (19200bps) • Default value: 9600bps
<p>Parity selection [c n P r]</p> <ul style="list-style-type: none"> • Selects the parity. • Not available when Serial communication (option) is not added or when Shinko protocol is selected in the Communication protocol selection. • Selecting item: none (No parity), Even (Even parity), odd (Odd parity) • Default value: Even parity
<p>Stop bit selection [c n 4 i]</p> <ul style="list-style-type: none"> • Selects the stop bit. • Not available when Serial communication (option) is not added or when Shinko protocol is selected in the Communication protocol selection. • Selecting item: 1 (1), 2 (2) • Default value: 1

5.5 Auxiliary function setting mode 2

In the PV/SV display mode, if the  key is pressed for approx. 3 seconds while the  and  keys are being pressed, Auxiliary function setting mode 2 can be selected.

The setting value can be increased or decreased by pressing the  or  key. If the  key is pressed, the setting value is registered and the next setting item is selected.

If Lock 3 is selected during Setting value lock selection, release Lock 3 (Unlock) first, then change desired setting items in Auxiliary function setting mode 2.

<p>Input type selection [4 E n 4]</p> <ul style="list-style-type: none"> • An input type from thermocouple (10 types), RTD (2 types), DC current (2 types) and DC voltage (4 types) and the unit °C/F can be selected. • Each time the input is changed from DC voltage to another type, remove the sensor connected to the controller first, then change to the input desired. Changing the input while the sensor is connected will cause malfunction of the input circuit. • Default value: K (-200 to 1370°C) 		
Input type	Input range	
K	-200 to 1370 °C: <i>E L</i>	-320 to 2500 °F: <i>E F</i>
	-199.9 to 400.0 °C: <i>E .L</i>	-199.9 to 750.0 °F: <i>E .F</i>
J	-200 to 1000 °C: <i>J L</i>	-320 to 1800 °F: <i>J F</i>
R	0 to 1760 °C: <i>r L</i>	0 to 3200 °F: <i>r F</i>
S	0 to 1760 °C: <i>s L</i>	0 to 3200 °F: <i>s F</i>
B	0 to 1820 °C: <i>b L</i>	0 to 3300 °F: <i>b F</i>
E	-200 to 800 °C: <i>E L</i>	-320 to 1500 °F: <i>E F</i>
T	-199.9 to 400.0 °C: <i>T .L</i>	-199.9 to 750.0 °F: <i>T .F</i>
N	-200 to 1300 °C: <i>n L</i>	-320 to 2300 °F: <i>n F</i>
PL-II	0 to 1390 °C: <i>PL.L</i>	0 to 2500 °F: <i>PL.F</i>
C(W/Re5-26)	0 to 2315 °C: <i>c L</i>	0 to 4200 °F: <i>c F</i>
Pt100	-199.9 to 850.0 °C: <i>PT .L</i>	-199.9 to 999.9 °F: <i>PT .F</i>
	-200 to 850 °C: <i>PT L</i>	-300 to 1500 °F: <i>PT F</i>

JPt100	-199.9 to 500.0 °C: <i>JPTC</i>	-199.9 to 900.0 °F: <i>JPTF</i>
	-200 to 500 °C: <i>JPTC</i>	-300 to 900 °F: <i>JPTF</i>
4 to 20mA DC	-1999 to 9999: <i>4204</i>	
0 to 20mA DC	-1999 to 9999: <i>0204</i>	
0 to 1V DC	-1999 to 9999: <i>0 18</i>	
0 to 5V DC	-1999 to 9999: <i>0 58</i>	
1 to 5V DC	-1999 to 9999: <i>1 58</i>	
0 to 10V DC	-1999 to 9999: <i>0 108</i>	
Scaling high limit setting [<i>HFLH</i>] <ul style="list-style-type: none"> • Sets scaling high limit value. • Available only for the DC input • Setting range: Scaling low limit value to input range high limit value (The placement of the decimal point follows the selection) • Default value: 9999 		
Scaling low limit setting [<i>HFL L</i>] <ul style="list-style-type: none"> • Sets scaling low limit value. • Available only for the DC input • Setting range: Input range low limit value to scaling high limit value (The placement of the decimal point follows the selection) • Default value: -1999 		
Decimal point place selection [<i>DP</i>] <ul style="list-style-type: none"> • Selects a decimal point place • Available only for the DC input • No decimal point : <i>0000</i> 1 digit after decimal point : <i>0000</i> • 2 digits after decimal point: <i>0000</i> 3 digits after decimal point : <i>0000</i> • Default value: No decimal point 		
PV filter time constant setting [<i>FILT</i>] <ul style="list-style-type: none"> • Sets PV filter time constant. • If the value is set too large, it affects control result due to the delay of response. • Setting range: 0.0 to 10.0 seconds • Default value: 0.0 seconds 		
OUT1 high limit setting [<i>OLH</i>] <ul style="list-style-type: none"> • Sets the high limit value for OUT1. • Not available for ON/OFF action • Setting range: OUT1 low limit value to 100% (relay contact output, non-contact voltage output) OUT1 low limit value to 105% (DC current output) • Default value: 100% 		
OUT1 low limit setting [<i>OLL</i>] <ul style="list-style-type: none"> • Sets the low limit value for OUT1. • Not available for ON/OFF action • Setting range: 0% to OUT1 high limit value (relay contact output, Non-contact voltage output) -5% to OUT1 high limit value (DC current output) • Default value: 0% 		
OUT1 ON/OFF action hysteresis setting [<i>HYH</i>] <ul style="list-style-type: none"> • Sets ON/OFF action hysteresis for OUT1. • Available only for ON/OFF action • Setting range: 0.1 to 100.0°C (°F) For DC input, 1 to 1000 (The placement of the decimal point follows the selection) • Default value 1.0°C 		

<p>OUT2 action mode selection [cAct]</p> <ul style="list-style-type: none"> • Selects a cooling action from Air cooling, Oil cooling and Water cooling. Not available when OUT2 is ON/OFF action or when the option Heating/Cooling control is not applied • <i>Air</i> : Air cooling (Linear characteristic) <i>oil</i> : Oil cooling (The 1.5th power of the linear characteristic) <i>water</i> : Water cooling (The 2nd power of the linear characteristic) • Default value: Air cooling 																				
<p>OUT2 high limit setting [oLHb]</p> <ul style="list-style-type: none"> • Sets the high limit value for OUT2. • Not available when OUT2 is ON/OFF action or when the option Heating/Cooling control is not applied • Setting range: OUT2 low limit value to 100% (relay contact output, non-contact voltage output) OUT2 low limit value to 105% (DC current output) • Default value: 100% 																				
<p>OUT2 low limit setting [oLLb]</p> <ul style="list-style-type: none"> • Sets the low limit value for OUT2. • Not available when OUT2 is ON/OFF action or when the option Heating/Cooling control is not applied • Setting range: 0% to OUT2 high limit value (relay contact output, Non-contact voltage output) -5% to OUT2 high limit value (DC current output) • Default value: 0% 																				
<p>Overlap band/Dead band setting [db]</p> <ul style="list-style-type: none"> • Sets overlap band and dead band value for OUT1 and OUT2. + setting value: Dead band - setting value: Overlap band • Available only when the option Heating/Cooling control is applied • Setting range: -100.0 to 100.0°C (°F) For DC input, -1000 to 1000 (The placement of the decimal point follows the selection) • Default value: 0.0°C 																				
<p>OUT2 ON/OFF action hysteresis setting [H94b]</p> <ul style="list-style-type: none"> • Sets ON/OFF action hysteresis for OUT2. • Not available when OUT2 is PID, PD or PI action or when the option Heating/Cooling control is not applied • Setting range: 0.1 to 100.0°C (°F) For DC input, 1 to 1000 (The placement of the decimal point follows the selection) • Default value: 1.0°C 																				
<p>A1 action selection [ALIF]</p> <ul style="list-style-type: none"> • Selects A1 action. • Selecting item: <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">No alarm action</td> <td style="width: 30%;">: ----</td> <td style="width: 30%;">Process high alarm</td> <td style="width: 10%;">: A4</td> </tr> <tr> <td>High limit alarm</td> <td>: H</td> <td>Process low alarm</td> <td>: rA4</td> </tr> <tr> <td>Low limit alarm</td> <td>: L</td> <td>High limit alarm with standby</td> <td>: H u</td> </tr> <tr> <td>High/Low limits alarm</td> <td>: HL</td> <td>Low limit alarm with standby</td> <td>: L u</td> </tr> <tr> <td>High/Low limit range alarm:</td> <td>u d</td> <td>High/Low limits alarm with standby:</td> <td>HL u</td> </tr> </table> • Default value: No alarm action 	No alarm action	: ----	Process high alarm	: A4	High limit alarm	: H	Process low alarm	: rA4	Low limit alarm	: L	High limit alarm with standby	: H u	High/Low limits alarm	: HL	Low limit alarm with standby	: L u	High/Low limit range alarm:	u d	High/Low limits alarm with standby:	HL u
No alarm action	: ----	Process high alarm	: A4																	
High limit alarm	: H	Process low alarm	: rA4																	
Low limit alarm	: L	High limit alarm with standby	: H u																	
High/Low limits alarm	: HL	Low limit alarm with standby	: L u																	
High/Low limit range alarm:	u d	High/Low limits alarm with standby:	HL u																	

<p>A2 action selection [<i>A2F</i>]</p> <ul style="list-style-type: none"> • Selects A2 action. • Available only when the option A2 is applied • The selecting item and default value are the same as those of A1 action selection.
<p>A1 action Energized/Deenergized selection [<i>A1L</i>]</p> <ul style="list-style-type: none"> • Selects A1 action Energized/Deenergized. • Not available when No alarm action is selected in A1 action selection • Selecting item: <i>noñL</i> (Energized), <i>rEB4</i> (Deenergized) • Default value: Energized
<p>A2 action Energized/Deenergized selection [<i>A2L</i>]</p> <ul style="list-style-type: none"> • Selects A2 action Energized/Deenergized. • Not available when No alarm action is selected in A2 action selection or when A2 (option) is not added • The selecting item and default value are the same as those of A1 action Energized/Deenergized selection.
<p>A1 hysteresis setting [<i>A1H</i>]</p> <ul style="list-style-type: none"> • Sets A1 hysteresis. • Not available when No alarm action is selected in A1 action selection • Setting range: 0.1 to 100.0°C (°F) For DC input, 1 to 1000 (The placement of the decimal point follows the selection) • Default value: 1.0°C
<p>A2 hysteresis setting [<i>A2H</i>]</p> <ul style="list-style-type: none"> • Sets A2 hysteresis. • Not available when No alarm action is selected in A2 action selection or when option A2 is not added • The setting range and default value are the same as those of A1 hysteresis setting.
<p>A1 action delayed timer setting [<i>A1d</i>]</p> <ul style="list-style-type: none"> • Sets the action delayed timer for A1. The alarm is activated when the setting time has passed after the input enters the alarm output range. • Not available when No alarm action is selected in A1 action selection • Setting range: 0 to 9999 seconds • Default value: 0 seconds
<p>A2 action delayed timer setting [<i>A2d</i>]</p> <ul style="list-style-type: none"> • Sets the action delayed timer for A2. The alarm is activated when the setting time has passed after the input enters the alarm output range. • Not available when No alarm action is selected in A2 action selection or when A2 (option) is not added • The setting range and default value are the same as those of A1 action delayed timer setting.
<p>Direct/Reverse action selection [<i>conf</i>]</p> <ul style="list-style-type: none"> • Sets the Direct (Cooling) or Reverse (Heating) action. • Selecting item Reverse (Heating): <i>HEAT</i> Direct (Cooling): <i>COOL</i> • Default value: Reverse (Heating)

<p>AT bias setting [<i>AT - b</i>]</p> <ul style="list-style-type: none"> • Sets the bias value when PID auto-tuning is performing. • Not available for DC input • Setting range: 0 to 50°C (0 to 100°F) With a decimal point, 0.0 to 50.0°C (0.0 to 100.0°F) • Default value: 20°C
<p>SVTC bias setting [<i>SV - b</i>]</p> <ul style="list-style-type: none"> • Control desired value adds SVTC bias value to the value received by the digital transmission. • Available only when Serial communication (option) is added • Setting range: Converted value of $\pm 20\%$ of the rated value For DC input, $\pm 20\%$ of the scaling span (The placement of the decimal point follows the selection) However, the negative minimum value is -1999, -199.9, -19.99 or -1.999. • Default value: 0
<p>SV2 indication selection [<i>SV 2</i>]</p> <ul style="list-style-type: none"> • Selects whether SV2 is indicated or not. • Not available when Serial communication (option) is added • Selecting item: <i>on</i> (Indication) <i>off</i> (No indication) • Default value: Indication
<p>Output status selection when input burnout [<i>EOU</i>]</p> <ul style="list-style-type: none"> • Selects the output status when input is burnt out. • Available only for DC current output type with DC input • Selecting item: <i>off</i> (Output OFF) <i>on</i> (Output ON) • Default value: Output OFF
<p>OUT/OFF key function selection [<i>AMU</i>]</p> <ul style="list-style-type: none"> • Selects the OUT/OFF key function. • Selecting item: <i>off</i> (OUT/OFF function), <i>AMU</i> (Auto/Manual control function) • Default value: OUT/OFF function

Sensor correction function

This corrects the input value from the sensor. When a sensor cannot be set at a location where control is desired, the sensor measuring temperature may deviate from the temperature in the controlled location. When controlling with plural controllers, the accuracy of sensors affects the control.

Therefore, sometimes the measured temperature (input value) does not concur with the same setting value. In such a case, the control can be set at the desired temperature by adjusting the input value of sensors.

Loop break alarm

The alarm will be activated when the process variable (PV) does not **rise** as much value as the span or greater within the time it takes to assess the Loop break alarm after the manipulated variable has reached 100% or the output high limit value. The alarm will also be activated when the process variable (PV) does not **fall** as much value as the span or greater within the time it takes to assess the Loop break alarm after the manipulated variable has reached 0% or the output low limit value.

When the control action is Direct (Cooling), read “**fall**” for “**rise**” and vice versa.

SV1/SV2 external selection

SV1 or SV2 can be selected by the external operation.

- Terminals between 13 and 14 open: SV1 can be selected.
- Terminals between 13 and 14 closed: SV2 can be selected.
- Setting value memory number cannot be changed during setting mode or PID auto-tuning.



Energized/Deenergized function

[If the alarm action Energized is selected]

When the alarm output indicator is lit, the alarm output (terminals 15-16 or 17-18) is conducted (ON). When the alarm output indicator is unlit, the alarm output is not conducted (OFF). See (Fig. 5.5-1).

[If the alarm action Deenergized is selected]

When the alarm output indicator is lit, the alarm output (terminals 15-16 or 17-18) is not conducted (OFF). When the alarm output indicator is unlit, the alarm output is conducted (ON). See (Fig. 5.5-2).



5.6 Control output OFF function

Control output OFF function [OFF]

- A function to pause the control action or turn the control output of the unused instrument of the plural units OFF even if the power to the instrument is supplied. [OFF] is indicated on the PV display while the function is working.
- Pressing the ① key (OUT/OFF key) for approx. 1 second from any mode turns the control output OFF. Pressing the ① key again for approx. 1 second cancels the control output OFF function.
- Once the Control output OFF function is enabled, the function cannot be released even if the power to the instrument is turned OFF and ON again. To cancel the function, press the ① key again for approx. 1 second.

5.7 Auto/Manual control function

PV/SV display mode (manual control)

- To use this function, it is necessary to select Auto/Manual control function during the OUT/OFF key function selection. First, press the ① key. The control can be performed by increasing or decreasing the manipulated variable (MV) on the SV display with the Δ and ∇ keys.
- The 1st decimal point from the right on the SV display blinks.
- By pressing the ① key again, the mode reverts to the PV/SV display (automatic control) mode. (When the power supply to the instrument is turned on, automatic control starts)
- When control is changed from automatic to manual or vice versa, the balanceless-bumpless function works to prevent sudden change of manipulated variable (MV).
- If Auto/Manual control function is selected, control output OFF function does not work.

5.8 Output manipulated variable indication

Output manipulated variable indication

- If pressing the ② key for approx. 3 seconds during PV/SV display mode, Output manipulated variable can be indicated on the SV display. During MV indication, the 1st decimal point from the right on the SV display blinks at a cycle of 0.5 second. By pressing the ② key again, the mode reverts to the PV/SV display mode.

6. Running

After the controller has been mounted to the control panel and wiring is completed, it can be started in the following manner.

(1) Turn the power supply to the JCM-33A Series ON.

With thermocouple and RTD input, sensor input character and temperature unit are indicated on the PV display and the input range high limit value is indicated on the SV display for approx. 3 seconds after the power is switched ON. See (Table 6-1).

With the DC input, sensor input character is indicated on the PV display and scaling high limit value is indicated on the SV display for approx. 3 seconds after the power is switched ON. See (Table 6-1).

However, if the scaling high limit value has been changed in the Scaling high limit setting, the changed value is indicated on the SV display.)

(During this time, all outputs and the LED indicators are in OFF status)

After that, control starts indicating the process variable on the PV display and SV1 or SV2 on the SV display.

(When the Control output OFF function is working, [OFF] is indicated on the PV display)

(Table 6-1)

Sensor input	°C		°F	
	PV display	SV display	PV display	SV display
K	K C	1310	K F	2500
	K L	4000	K F	7500
J	J C	1000	J F	1800
R	r C	1760	r F	3200
S	s C	1760	s F	3200
B	b C	1820	b F	3300
E	E C	800	E F	1500
T	T C	4000	T F	7500
N	n C	1300	n F	2300
PL-II	PL2C	1390	PL2F	2500
C (W/Re5-26)	c C	2315	c F	4200
Pt100	PT C	8500	PT F	9999
	PT L	850	PT F	1500
JPt100	JPT C	5000	JPT F	9000
	JPT L	500	JPT F	900
4 to 20mA DC	420A	Scaling high limit value		
0 to 20mA DC	020A			
0 to 1V DC	0 18			
0 to 5V DC	0 58			
1 to 5V DC	1 58			
0 to 10V DC	0 108			

(2) Input each setting value.

Input each setting value, referring to "5. Setup".

(3) Turn the load circuit power ON.

Starts the control action so as to keep the controlled object at the main setting value.

7. Action explanation

7.1 OUT1 action

	Heating (reverse) action			Cooling (direct) action		
Control action						
Relay contact output R/□						
Non-contact voltage output S/□						
DC current output A/□						
Indication (OUT1) Green						

: Acts ON (lit) or OFF (unlit).


7.2 Heater burnout alarm action (option)

Heater burnout alarm action	
Heater burnout alarm output	
Indication (HB) red	

When Heating/Cooling control (option) is applied, use terminals 17 and 18 for the Heater burnout alarm. When A2 output (option) is applied, use terminals 8 and 9 for the Heater burnout alarm.

7.3 OUT1 ON/OFF action

	Heating (reverse) action		Cooling (direct) action	
Control action				
Relay contact output R/ □				
Non-contact voltage output S/ □				
DC current output A/ □				
Indication (OUT1) Green				

 : Acts ON (lit) or OFF (unlit).

7.4 OUT2 (Heating/Cooling control) action (Option)

Control action			
Relay contact output (OUT1) R/□			
Relay contact output (OUT2) DR			
Non-contact voltage output (OUT1) S/□			
Non-contact voltage output (OUT2) DS			
DC current output (OUT1) A/□			
DC current output (OUT2) DA			
Indication (OUT1) Green			
Indication (OUT2) Yellow			

: Acts ON (lit) or OFF (unlit).

————— : Represents Heating control action.

- - - - - : Represents Cooling control action.

When setting Dead band

Control action			
Relay contact output (OUT1) R/□			
	Cycle action is performed according to deviation.		
Relay contact output (OUT2) DR			
	Cycle action is performed according to deviation.		
Non-contact voltage output (OUT1) S/□			
	Cycle action is performed according to deviation.		
Non-contact voltage output (OUT2) DS			
	Cycle action is performed according to deviation.		
DC current output (OUT1) A/□			
	Changes continuously according to deviation.		
DC current output (OUT2) DA			
	Changes continuously according to deviation.		
Indication (OUT1) Green			Unlit
Indication (OUT2) Yellow			Lit

: Acts ON (lit) or OFF (unlit).

————— : Represents Heating control action.

- - - - - : Represents Cooling control action.

When setting Overlap band

Control action			
Relay contact output (OUT1) R/□	<p>Cycle action is performed according to deviation.</p>		
Relay contact output (OUT2) DR	<p>Cycle action is performed according to deviation.</p>		
Non-contact voltage output (OUT1) S/□	<p>Cycle action is performed according to deviation.</p>		
Non-contact voltage output (OUT2) DS	<p>Cycle action is performed according to deviation.</p>		
DC current output (OUT1) A/□	<p>Changes continuously according to deviation.</p>		
DC current output (OUT2) DA	<p>Changes continuously according to deviation.</p>		
Indication (OUT1) Green			
Indication (OUT2) Yellow			


: Acts ON (lit) or OFF (unlit).

————— : Represents Heating control action.

- - - - - : Represents Cooling control action.

7.5 A1 and A2 actions

	High limit alarm	Low limit alarm
Alarm action		
Alarm output		
	High/Low limits alarm	High/Low limit range alarm
Alarm action		
Alarm output		
	Process high alarm	Process low alarm
Alarm action		
Alarm output		
	High limit alarm with standby	Low limit alarm with standby
Alarm action		
Alarm output		



: A1 output terminals 15 and 16 are connected (ON).

: A1 output terminals 15 and 16 are connected (ON) or disconnected (OFF).

: A1 output terminals 15 and 16 are disconnected (OFF).

: Standby functions.

For A2 output, terminals 17 and 18 are used.

A1 and A2 indicators light up when their output terminals are connected (ON), and go out when their output terminals are disconnected (OFF).

7.6 SV1/SV2 external selection action

	SV1	SV2
setting value memory external selection		
Indication Green	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">SV1 Lit</div> <div style="border: 1px solid black; padding: 2px;">SV2 Unlit</div> </div>	<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 2px;">SV1 Unlit</div> <div style="border: 1px solid black; padding: 2px;">SV2 Lit</div> </div>

This function is not available if Serial communication (option) is applied.

8. Control action explanations

8.1 PID

(1) Proportional band (P)

Proportional action is the action which the control output varies in proportion to the deviation between the setting value and the processing temperature.

If the proportional band is narrowed, even if the output changes by a slight variation of the processing temperature, better control results can be obtained as the offset decreases.

However, if the proportional band is narrowed too much, even slight disturbances may cause variation in the processing temperature, control action changes to ON/OFF action and the so-called hunting phenomenon occurs.

Therefore, when the processing temperature comes to the balanced position near the setting value and a constant temperature is maintained, the most suitable value is selected by gradually narrowing the proportional band while observing the control results.

(2) Integral time (I)

Integral action is used to eliminate offset. When the integral time is shortened, the returning speed to the setting point is accelerated. However, the cycle of oscillation is also accelerated and the control becomes unstable.

(3) Derivative time (D)

Derivative action is used to restore the change in the processing temperature according to the rate of change. It reduces the amplitude of overshoot and undershoot width.


If the derivative time is shortened, restoring value becomes small, and if the derivative time is made longer, an excessive returning phenomenon may occur and the control system may be oscillated.

8.2 PID auto-tuning of this controller

In order to decide each value of P, I, D and ARW automatically, this system forcibly fluctuates the object being controlled.

(1) When the difference between the setting value and processing temperature is large as the temperature rises.


Fluctuation is applied at the temperature 20°C lower than the setting value.



(Fig. 8.2-1)

(2) When the control is stable or when control temperature is within $\pm 20^{\circ}\text{C}$ ($^{\circ}\text{F}$) of setting value.


Fluctuation is applied at the setting value.



(Fig. 8.2-2)

(3) When the control temperature is 20°C ($^{\circ}\text{F}$) or higher than the setting value.

Fluctuation is applied at the temperature 20°C ($^{\circ}\text{F}$) higher than the setting value.




(Fig. 8.2-3)

8.3 Auto-reset (offset correction)

Auto-reset is performed to correct the offset at the point at which PV indication is stabilized within the proportional band during the PD action.

Since the corrected value is internally memorized, it is not necessary to perform the auto-reset again as long as the process is the same.

However, when the proportional band is set to 0, the corrected value is cleared.



(Fig. 8.3-1)

9. Specifications

9.1 Standard specifications

Mounting method : Flush
Setting method : Membrane sheet key
Display

PV display : Red LED 4 digits, character size, 14.3 x 8 (H x W)mm
SV display : Green LED 4 digits, character size, 10 x 5.5 (H x W)mm

Accuracy (Setting, indication)

Thermocouple : Within $\pm 0.2\%$ of input range full scale ± 1 digit or within $\pm 2^\circ\text{C}$ (4°F), whichever is greater
However, R, S input, 0 to 200°C (0 to 400°F): Within $\pm 6^\circ\text{C}$ (12°F)
B input, 0 to 300°C (0 to 600°F): Accuracy is not guaranteed.
K, J, E, T, N input, less than 0°C (32°F): Within $\pm 0.4\%$ of input range full scale ± 1 digit
RTD : Within $\pm 0.1\%$ of input range full scale ± 1 digit or within $\pm 1^\circ\text{C}$ (2°F), whichever is greater
DC current and voltage: Within $\pm 0.2\%$ of input range full scale ± 1 digit

Input sampling period : 0.25 seconds

Input

Thermocouple : K, J, R, S, B, E, T, N, PL-II, C (W/Re5-26)
External resistance, 100Ω or less, however, for B, 40Ω or less
RTD : Pt100, JPt100, 3-wire system
Allowable input lead wire resistance, 10Ω or less per wire
DC current : 0 to 20mA DC, 4 to 20mA DC
Input impedance, 50Ω
[50Ω shunt resistor (sold separately) must be connected between input terminals]
Allowable input current, 50mA or less
[When 50Ω shunt resistor (sold separately) is used]
DC voltage : 0 to 1V DC
Input impedance, $1M\Omega$ or greater
Allowable input voltage, 5V or less
Allowable signal source resistance, $2k\Omega$ or less
0 to 5V DC, 1 to 5V DC, 0 to 10V DC
Input impedance, $100k\Omega$ or greater
Allowable input voltage, 15V or less
Allowable signal source resistance, 100Ω or less

Control output (OUT1)

Relay contact : 1a1b
Control capacity, 3A 250V AC (resistive load)
1A 250V AC (inductive load $\cos\phi=0.4$)
Electrical life, 100,000 times
Non-contact voltage: 12_0^{+2} V DC maximum 40mA (short circuit protected)
The connectable SSRs in parallel are 4 units if Shinko SSRs (SA-200 series) are used.
DC current : 4 to 20mA DC
Load resistance, maximum 550Ω

A1 output

When A1 action is set as energized, the alarm action point is set by \pm deviation to the main setting (except Process alarm).

When the input goes outside the range, the output turns ON or OFF (in the case of High/Low limit range alarm).

When the alarm action is set as deenergized, the output acts conversely.

Setting accuracy : The same as the Indicating accuracy

Action : ON/OFF action

Hysteresis : Thermocouple and RTD input, 0.1 to 100.0°C (°F)
DC current and DC voltage input, 1 to 1000
(The placement of the decimal point follows the selection)

Output : Relay contact 1a
Control capacity, 3A 250V AC (resistive load)
Electrical life, 100,000 times

Control action

- PID action (with auto-tuning function)
- PI action: When derivative time is set to 0
- PD action (with auto-reset function): When integral time is set to 0
- P action (with auto-reset function): When integral and derivative times are set to 0
- ON/OFF action: When OUT1 proportional band is set to 0

OUT1 proportional band (P):

Thermocouple, 0 to 1000°C (0 to 2000°F)
RTD, 0.0 to 999.9°C (0.0 to 999.9°F)
DC current and voltage, 0.0 to 100.0%
(ON/OFF action when set to 0°C (°F), 0.0°C (°F) or 0.0%)

Integral time (I) : 0 to 1000s (off when set to 0)

Derivative time (D) : 0 to 300s (off when set to 0)

OUT1 proportional cycle : 1 to 120s (Not available for DC current output type)

ARW : 0 to 100%

OUT1 hysteresis : Thermocouple and RTD input, 0.1 to 100.0°C (°F)
DC current and voltage input, 1 to 1000
(The placement of the decimal point follows the selection)

Supply voltage : 100 to 240V AC 50/60Hz, 24V AC/DC 50/60Hz

Allowable voltage fluctuation range

100 to 240V AC : 85 to 264V AC


24V AC/DC : 20 to 28V AC/DC

Ambient temperature: 0 to 50°C (32 to 122°F)

Ambient humidity : 35 to 85%RH (no condensation)

Power consumption : Approx. 8VA

Circuit isolation configuration



- When OUT1 is non-contact voltage or DC current output type and when OUT2 is Non-contact voltage or DC current output type, A to B is non-isolated.
- When OUT1 is non-contact voltage or DC current output type, A to C and A to D are non-isolated.
When OUT2 is non-contact voltage or DC current output type, B to C and B to D are non-isolated.

Isolation resistance

10M Ω or greater at 500V DC for other combinations except the above mentioned

Dielectric strength

Between input terminal and ground terminal, 1.5kV AC for 1 minute
 Between input terminal and power terminal, 1.5kV AC for 1 minute
 Between output terminal and ground terminal, 1.5kV AC for 1 minute
 Between output terminal and power terminal, 1.5kV AC for 1 minute
 Between power terminal and ground terminal, 1.5kV AC for 1 minute

Weight : Approx. 300g

External dimension: 72 x 72 x 100mm (W x H x D)

Material : Case, Flame resistant resin

Color : Case, Light gray

Attached function

[Sensor correction function]

[Setting value lock function]

[Input burnout indication]

For thermocouple or RTD input, if the input value exceeds the Indication range high limit value, the PV display blinks “- - - -” and if the input value goes under the Indication range low limit value, the PV display blinks “- - - -”.

If the input value goes outside the Control range, OUT1 and OUT2 is turned OFF (for DC current output, OUT1 low limit value and OUT2 low limit value).

(However, for manual control, it outputs the preset manipulated variable)

Input	Input range	Indication range	Control range
K, T	-199.9 to 400.0°C	-199.9 to 450.0°C	-205.0 to 450.0°C
	-199.9 to 750.0°F	-199.9 to 850.0°F	-209.0 to 850.0°F
K	-200 to 1370°C	-250 to 1420°C	-250 to 1420°C
	-320 to 2500°F	-370 to 2550°F	-370 to 2550°F
J	-200 to 1000°C	-250 to 1050°C	-250 to 1050°C
	-320 to 1800°F	-370 to 1850°F	-370 to 1850°F
R, S	0 to 1760°C	-50 to 1810°C	-50 to 1810°C
	0 to 3200°F	-50 to 3250°F	-50 to 3250°F
B	0 to 1820°C	-50 to 1870°C	-50 to 1870°C
	0 to 3300°F	-50 to 3350°F	-50 to 3350°F
E	-200 to 800°C	-250 to 850°C	-250 to 850°C
	-320 to 1500°F	-370 to 1550°F	-370 to 1550°F
N	-200 to 1300°C	-250 to 1350°C	-250 to 1350°C
	-320 to 2300°F	-370 to 2350°F	-370 to 2350°F
PL-II	0 to 1390°C	-50 to 1440°C	-50 to 1440°C
	0 to 2500°F	-50 to 2550°F	-50 to 2550°F
C(W/Re5-26)	0 to 2315°C	-50 to 2365°C	-50 to 2365°C
	0 to 4200°F	-50 to 4250°F	-50 to 4250°F
Pt100	-199.9 to 850.0°C	-199.9 to 900.0°C	-210.0 to 900.0°C
	-200 to 850°C	-210 to 900°C	-210 to 900°C
	-199.9 to 999.9°F	-199.9 to 999.9°F	-211.0 to 1099.9°F
	-300 to 1500°F	-318 to 1600°F	-318 to 1600°F
JPt100	-199.9 to 500.0°C	-199.9 to 550.0°C	-206.0 to 550.0°C
	-200 to 500°C	-207 to 550°C	-207 to 550°C
	-199.9 to 900.0°F	-199.9 to 999.9°F	-211.0 to 999.9°F
	-300 to 900°F	-312 to 1000°F	-312 to 1000°F

For DC current and voltage input, if the input value exceeds the Indication range high limit value, the PV display blinks “- - - -” and if the input value goes under the Indication range low limit value, the PV display blinks “- - - -”. If the input value goes outside the Control range, OUT1 and OUT2 are turned ON or OFF which has been selected in [Output status selection when input burnout] (for DC current output, OUT1 high or low limit value and OUT2 high or low limit value). (However, for manual control, it outputs the preset manipulated variable)

Indication range : [Scaling low limit value – Scaling span x 1%] to [Scaling high limit value + Scaling span x 10%]
However, if the input value is out of the range –1999 to 9999, the PV display blinks “- - - -” or “- - - -”.

Control range : [Scaling low limit value – Scaling span x 1%] to [Scaling high limit value + Scaling span x 10%]

DC input burnout: When DC input is burnt out, PV display blinks “- - - -” for 4 to 20mA DC and 1 to 5V DC input, and “- - - -” for 0 to 1V DC input.

For 0 to 20mA DC, 0 to 5V DC and 0 to 10V DC input, the PV display indicates the corresponding value for which 0mA or 0V is inputted.

[Burnout]

When the thermocouple or RTD input is burnt out, OUT1 is turned off (for DC current output type, OUT1 low limit value) and the PV display blinks “- - - -”.

[Self-diagnosis]

The CPU is monitored by a watchdog timer, and when any abnormal status is found on the CPU, the controller is switched to warm-up status.

[Automatic cold junction temperature compensation](Thermocouple input type)

This detects the temperature at the connecting terminal between thermocouple and the instrument, and always keeps it on the same status as when the reference junction is located at 0°C [32°F].

[Power failure countermeasure]

The setting data is backed up in non-volatile IC memory.

[Warm-up indication]

With thermocouple and RTD input, for approx. 3 seconds after the power is switched ON, sensor input character and temperature unit are indicated on the PV display, and the input range high limit value is indicated on the SV display. With the DC input, for approx. 3 seconds after the power is switched ON, sensor input character is indicated on the PV display, and scaling high limit value is indicated on the SV display.

(However, if the scaling high limit value has been changed in the Scaling high limit setting, the changed value will be indicated on the SV display.)

[Auto/Manual control switching]

If Auto/Manual control function is selected during OUT/OFF key function selection, automatic control can be switched to manual control or vice versa by pressing the OUT/OFF key.

When the control action is changed from automatic to manual control and vice versa, the balanceless-bumpless function works to prevent sudden change of manipulated variable.

When the control action is changed from automatic to manual control, the 1st decimal point from the right on the SV display blinks.

The control can be performed by increasing or decreasing the manipulated variable (MV) with the \triangle or ∇ key.

(When the power supply to the instrument is turned on, automatic control starts)

Accessories:

Instruction manual	1 copy
Screw type mounting bracket	1 set
CT (current transformer)	
CTL-6S [Option W (5A, 10A, 20A)]	1 piece
CTL-12-S36-10L1 [Option W (50A)]	1 piece
Terminal cover	1 piece (when option TC is added)

9.2 Optional specifications

Alarm 2 (option code: A2)

When A2 action is set as Energized, the alarm action point is set by \pm deviation to main setting (except Process alarm).

When the input goes outside the range, the output turns ON or OFF (in the case of High/Low limit range alarm).

When the alarm action is set as Deenergized, the output acts conversely.

- When option A2 and LA are added together, they share common output terminals.

Setting accuracy: The same as the Indicating accuracy
 Action : ON/OFF action
 Hysteresis : For thermocouple and RTD input, 0.1 to 100.0°C (°F)
 For DC current and voltage input, 1 to 1000
 (The placement of the decimal point follows the selection)
 Output : Relay contact 1a
 Control capacity, 3A 250V AC (resistive load)
 Electrical life, 100,000 times

Heater burnout alarm (option code: HB)

Watches the heater current with CT (current transformer), and detects the heater burnout.

Heater burnout alarm is activated when sensor is burnt out or when indication is overscale or underscale.

- This option cannot be applied to DC current output type.

Heater rated current: 5A, 10A, 20A, 50A, Must be specified
 Setting accuracy : Within $\pm 5\%$ of heater rated current
 Action : ON/OFF action
 Output : Relay contact 1a
 Control capacity, 3A 250V AC (resistive load)
 Electrical life, 100,000 times

Heating/Cooling control (option code: DR, DS, DA)

OUT2 proportional band : 0.0 to 10.0 times OUT1 proportional band
 (ON/OFF action when set to 0.0)

OUT2 integral time : The same as that of OUT1

OUT2 derivative time : The same as that of OUT1

OUT2 proportional cycle : 1 to 120 seconds

Overlap band/Dead band:

For thermocouple and RTD input, -100.0 to 100.0°C (°F)

For DC current and voltage input, -1000 to 1000

(The placement of the decimal point follows the selection)

OUT2 ON/OFF action hysteresis

For thermocouple and RTD input, 0.1 to 100.0°C (°F)

For DC current and voltage input, 1 to 1000

(The placement of the decimal point follows the selection)

Output Relay contact output 1a

Control capacity, 3A 250V AC (resistive load)

1A 250V AC (inductive load $\cos\phi=0.4$)

Electrical life, 100,000 times

Non-contact voltage output

$12^{\pm 2}_0\text{V}$ DC maximum 40mA (short circuit protected)

DC current output, 4 to 20mA DC

Load resistance, maximum 550 Ω

OUT2 action mode selection function:

One cooling mode can be selected by keypad operation from the following.

Air cooling (Linear characteristic)

Oil cooling (1.5th power of the linear characteristic)

Water cooling (2nd power of the linear characteristic)

SV1/SV2 external selection (option code: SM)

SV1 and SV2 can be selected by external contact.

Contact open between terminals 13 and 14 : SV1

Contact closed between terminals 13 and 14: SV2

Contact current: 6mA

Serial communication (Option code: C5)

If Serial communication is added, SV1/SV2 external selection function does not work. The following operations are performed from the external computer.

- (1) Reading and setting of the main setting value, PID and various other setting values
- (2) Reading of the input value and action status
- (3) Function change

Communication line : Based on EIA RS-485
 Communication method : Half-duplex start-stop synchronous
 Communication speed : 2400/4800/9600/19200bps(Selectable by keypad operation)
 Parity : Even/Odd/No (Selectable by keypad operation)
 Stop bit : 1 or 2 (Selectable by keypad operation)

Data format

Communication protocol	Shinko protocol	Modbus ASCII	Modbus RTU
Start bit	1	1	1
Data bit	7	7	8
Parity	Even	Selectable (Even)	Selectable (No)
Stop bit	1	Selectable (1)	Selectable (1)

Data bit is automatically switched by the selection of the communication protocol.

() shows basic setting value.

Digital external setting:

Receives digital setting value from Shinko programmable controller (with option SVTC). [Setting value Lock of the JCM-33A must be set to Lock 3.]

When SV data from Shinko programmable controller is greater than SV high limit or smaller than SV low limit, JCM-33A ignores the value and controls with the SV high limit or SV low limit.

Loop break alarm (option code: LA)

Detects the breaking status on the loop such as heater burnout, sensor burnout or actuator trouble.

The output terminals will be common if the options [LA] and [A2] are applied together.

Setting range : Loop break alarm action time, 0 to 200minutes

Loop break alarm action span, 0 to 150°C(F), 0.0 to 150.0°C(F),

For DC input, 0 to 1500 (The placement of the decimal point follows the selection)

Output : Relay contact 1a, 3A 250V AC (Resistive load)
 Electrical life, 100,000 times

Isolated power output (option code: P24)

Output voltage: 24±3V DC (when load current is 30mA)

Ripple voltage: Within 200mV (when load current is 30mA)

Maximum load current: 30mA

Color Black (option code: BK)

Front panel frame and case: Black

Terminal cover (option code: TC)

Electrical shock protecting terminal cover

Dust-proof/Drip-proof (option code: IP)

Dust-proof/Drip-proof specification, IP54

9.3 Option combination

	A2	LA	W	D□	P24	C5	SM	BK	TC	IP
Combination 1	○	○	○	—	—	○	—	○	○	○
Combination 2	○	○	—	○	—	○	—	○	○	○
Combination 3	—	—	○	○	—	○	—	○	○	○
Combination 4	○	○	—	—	○	○	—	○	○	○
Combination 5	○	○	○	—	—	—	○	○	○	○
Combination 6	○	○	—	○	—	—	○	○	○	○
Combination 7	—	—	○	○	—	—	○	○	○	○
Combination 8	○	○	—	—	○	—	○	○	○	○

D□: DR, DS, DA

10. Troubleshooting

If any malfunctions occur, refer to the following items after checking the power of the controller.



Warning

Turn the power supply to the instrument off before wiring or checking. Working or touching the terminal with the power switched on may result in severe injury or death due to Electric Shock.

Indication

Problem	Presumed cause and solution
The PV display is indicating [OFF].	<ul style="list-style-type: none"> Control output OFF function is working. Press the ① key (OUT/OFF key) for approx. 1 second to release the function.
[----] is blinking on the PV display.	<ul style="list-style-type: none"> The sensor for thermocouple, RTD and DC voltage (0 to 1V DC) input may be burnt out. Replace each sensor. <p>How to check sensor burnout</p> <p>[Thermocouple] If the input terminal of the instrument is shorted, and if nearby room temperature is indicated, the instrument is probably normal and the sensor may be burnt out.</p> <p>[RTD] If approx. 100Ω resistance is connected to the input terminal between A-B of the instrument and between B-B is shorted, and if a value around 0°C (32°F) is indicated, the instrument is probably normal and the sensor may be burnt out.</p> <p>[DC voltage (0 to 1V DC)] If the input terminal of the instrument is shorted, and if scaling low limit value is indicated, the instrument is probably normal and the signal wire may be burnt out.</p> Is the input terminal of thermocouple, RTD or DC voltage (0 to 1V DC) securely mounted to the instrument terminal? Connect the sensor terminal to the instrument terminal securely.
[----] is blinking on the PV display.	<ul style="list-style-type: none"> The sensor for DC voltage (1 to 5V DC) or DC current (4 to 20mA DC) input may be burnt out. Replace each sensor. <p>How to check sensor burnout</p> <p>[DC voltage (1 to 5V DC)] If the input to the input terminal of this controller is 1V DC and if scaling low limit value is indicated, the controller is probably normal and the signal wire may be burnt out.</p> <p>[DC current (4 to 20mA DC)] If the input to the input terminal of this controller is 4mA DC and if scaling low limit value is indicated, the controller is probably normal and the sensor may be burnt out.</p>

<p>[- - - -] is blinking on the PV display.</p>	<ul style="list-style-type: none"> • Is the input terminal of DC voltage (1 to 5V DC) and DC current (4 to 20mA DC) securely connected to the input terminal of this controller? Connect the sensor terminal to the controller terminal securely. • Polarity of thermocouple or compensating lead wire is reversed? Do codes (A, B, B) of RTD agree with the controller terminals? Wire them properly.
<p>The value set during the Scaling low limit setting remains on the PV display.</p>	<ul style="list-style-type: none"> • Is the sensor for DC voltage (0 to 5V DC, 0 to 10V DC) or DC current (0 to 20mA DC) input burnt out? Replace each sensor. How to check sensor burnout [DC voltage (0 to 5V DC, 0 to 10V)] If the input to the input terminal of this controller is 1V DC and if the corresponding value is indicated, the controller is probably normal and the sensor may be burnt out. [DC current (0 to 20mA DC)] If the input to the input terminal of this controller is 1mA DC and if the corresponding value is indicated, the controller is probably normal and the sensor may be burnt out. • Is the input terminal for DC voltage (0 to 5V DC, 0 to 10V DC) and DC current (0 to 20mA DC) securely connected to the controller terminal? Connect the sensor terminal to the controller terminal securely.
<p>The indication of PV display is abnormal or unstable.</p>	<ul style="list-style-type: none"> • Designation of the sensor input or temperature unit (°C or °F) is improper. Set the sensor input and the temperature unit properly. • Sensor correcting value is unsuitable. Set the value suitably. • Sensor specification is improper. Set the sensor specification properly. • AC may be leaking into the sensor circuit. Change the sensor for the ungrounded type. • There may be equipment nearby producing an inductive fault or noise near the controller. Keep the equipment producing an inductive fault or noise away from the controller.
<p>[Err t] is indicated on the PV display.</p>	<p>The internal memory is defective. Please contact our main office or dealers.</p>

Key operation

Problem	Presumed cause and solution
<p>Settings (main setting value, P, I, D, proportional cycle, alarm, etc.) are impossible. The value does not change by the \triangle, ∇ keys.</p>	<ul style="list-style-type: none"> • Setting value lock (Lock 1 or Lock 2) is designated. Release the lock designation. • During PID auto-tuning or auto-reset. Cancel the auto-tuning if necessary. Auto-reset ends in 4 minutes after starting.

The setting indication does not change within the rated input even if the \triangle , ∇ keys are pressed, and settings are impossible.	<ul style="list-style-type: none"> SV high limit or low limit may be set at the point the value does not change. Set it again in Auxiliary function setting mode 1.
---	--

Control

Problem	Presumed cause and solution
Process variable (temperature) does not rise.	<ul style="list-style-type: none"> The sensor is out of order. Replace the sensors. Sensor is not securely mounted to the instrument input terminal, or control output terminal is not securely mounted to the actuator input terminal. Mount the sensor or control output terminal securely. Is wiring of sensor terminal or control output terminal correct? Wire it correctly.
If the control output remains ON status.	<ul style="list-style-type: none"> OUT1 low limit value is set to 100% or greater in Auxiliary function setting mode 2. Set the value appropriately.
If the control output remains OFF status.	<ul style="list-style-type: none"> OUT1 high limit value is set to 0% or less in Auxiliary function setting mode 2. Set the value appropriately.

If any unexplained malfunctions occur, make inquiries at our agency or us.

11. Character table

Photocopiable material

[Main setting mode]

Character	Setting item	Default value	Data
SV1	SV1	0°C	
SV2	SV2	0°C	

[Sub setting mode]

Character	Setting item	Default value	Data
AT	AT setting	----	
r4EF	Auto-reset setting		
P	OUT1 proportional band setting	10°C	
P_b	OUT2 proportional band setting	1.0 times	
I	Integral time setting	200s	
d	Derivative time setting	50s	
n	ARW setting	50%	
c	OUT1 proportional cycle setting	30s or 3s	
c_b	OUT2 proportional cycle setting	30s or 3s	
$A1$	A1 setting	0°C	
$A2$	A2 setting	0°C	
H	HB (Heater burnout alarm) setting	0.0A	
LP_T	LA (Loop break alarm) action time	0 minutes	
LP_H	LA (Loop break alarm) action span	0°C	

[Auxiliary function setting mode 1]

Character	Setting item	Default value	Data
<i>Loct</i>	Setting value lock selection	Unlock	
<i>4H</i>	SV high limit setting	Input range high limit value	
<i>4L</i>	SV low limit setting	Input range low limit value	
<i>4o</i>	Sensor correction setting	0.0°C	
<i>cn4L</i>	Communication protocol selection	Shinko protocol	
<i>cnno</i>	Instrument number setting	0	
<i>cn4P</i>	Communication speed selection	9600bps	
<i>cnPr</i>	Parity selection	Even	
<i>cn4I</i>	Stop bit selection	1	

[Auxiliary function setting mode 2]

Character	Setting item	Default value	Data
<i>4En4</i>	Input type selection	K: -200 to 1370°C	
<i>4FLH</i>	Scaling high limit setting	9999	
<i>4FLl</i>	Scaling low limit setting	-1999	
<i>dP</i>	Decimal point place selection	No decimal point	
<i>FILF</i>	PV filter time constant setting	0.0 seconds	
<i>oLH</i>	OUT1 high limit setting	100%	
<i>oLL</i>	OUT1 low limit setting	0%	
<i>H44</i>	OUT1 ON/OFF action hysteresis	1.0°C	
<i>cRcF</i>	OUT2 action mode selection	Air cooling	
<i>oLHb</i>	OUT2 high limit setting	100%	
<i>oLLb</i>	OUT2 low limit setting	0%	
<i>db</i>	Overlap band/Dead band setting	0.0°C	
<i>H44b</i>	OUT2 ON/OFF action hysteresis	1.0°C	
<i>AL1F</i>	A1 action selection	No alarm	
<i>AL2F</i>	A2 action selection	No alarm	
<i>A1Lā</i>	A1 action Energized/Deenergized	Energized	
<i>A2Lā</i>	A2 action Energized/Deenergized	Energized	
<i>A1H4</i>	A1 hysteresis setting	1.0°C	
<i>A2H4</i>	A2 hysteresis setting	1.0°C	
<i>A1d4</i>	A1 action delayed timer setting	0 seconds	
<i>A2d4</i>	A2 action delayed timer setting	0 seconds	
<i>conF</i>	Direct (Cooling)/Reverse (Heating) action selection	Reverse (Heating) action	
<i>RF_b</i>	AT bias setting	20°C	
<i>4B_b</i>	SVTC bias setting	0	
<i>4B2</i>	SV2 indication selection	Indication	
<i>EoUF</i>	Output status selection when input burnout	Output OFF	
<i>āRnU</i>	OUT/OFF key function selection	OUT/OFF function	

***** Inquiry *****

For any inquiries about this unit, please contact our agency or the shop where you purchased the unit after checking the following.

- [Example]
- Model ----- JCM-33A-R/M
 - Input type ----- K
 - Option ----- A2, C5
 - Instrument number ----- No. xxxxxx

**SHINKO TECHNOS CO.,LTD.
OVERSEAS DIVISION**

Fastron Technologies Pty Ltd
25 Kingsley Close Rowville, Victoria, Australia 3178
Tel: +61 3 9763 5155 Fax: +61 3 9763 5166
E-mail: sales@fastron.com.au Web: www.fastron.com.au

No.JCM31E2 2003.09